IIDASH PANAMSE®

MOUNTING LOCATION: Right side of center air vent V R

TOOLS REQUIRED:

Hook tool
Phillips screwdriver, power
PARTS INCLUDED:

(3) F- #8x1/2 Phillips PanHead Tap Screw (1) S7140-106 Mount

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75140-106 MFG: PETERBILT MODELS & YEARS: Conventional 2006-2019 Partially Inclusive of the Following 365,367,377,378,379,384,386,388,389

STEP #1: With hook tool assist, remove the thin strip below the center air vents and above switches. Start from the right side, lift up to release (3) clips and tilt it out to release lip from left side of strip.

STEP #2: With Phillips screwdriver remove the (2) screws exposed that hold the dash cover in place. With your hands pull on the dash cover to release (4) peg clips. Do not try to remove the plate completely. Pull out only enough to get a power screwdriver in to install the screws.

STEP #3: Place Mount to right side of center air vent. Carefully install (3) supplied self drilling/tapping screws. It is best to use a power drill.

STEP #4: Snap the dash cover back into place. It may be necessary to pull out the clips slightly (1/8"-1/4") on the trim strip to help it stay in place when it is replaced. Also straightening of the clip lips could help seat the clip better into the dash.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

I-75140-106

Page 1 of 1

* * ADVISEMENT * *

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Dash strip



Clip to pull out slightly



InDash installed showing location



InDash fit into location with screw



Location detail



06-28-18