

INDASH by PANAVISE®

751073015

Page 1 of 1

MOUNTING LOCATION:

In Front of Center Seat

TOOLS REQUIRED:

Phillips Head Screwdriver

Drill w/5mm bit, M6 -1.00 Tap

4 mm Allen Wrench

HARDWARE INCLUDED:

(2) 6M -1.00x20mm, Flat Head Socket Cap

Screw-BLK.

COMMUNICATIONS DEVICE MOUNT

INSTALLATION INSTRUCTIONS

PART#: 751073015

MFG: FORD

MODELS & YEARS:

**F150 2015-2017. w/Center Seat
F250, F350 2017. w/Center Seat
F450/550 2017, CntrSeat, w/o Floor Shift
With Kenwood NX700/800 2Way Radio,
Other Radios TBD, Drill to Universal Fit**

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Open the lower cover of the center seat compartment. Remove the snap-in cup holder, as it will not be available for use with this mount.

STEP #2: With T20 Torx driver, remove the 2 screws at the front top of the seat compartment base.

STEP #3: Take the 5mm Drill Bit and drill out the 2 holes, and tap the 2 holes with M6 -1.00 Tap

STEP #4: Install the radio bracket onto the mount with the (4) screws supplied by the radio manufacturer.

STEP #5: Place the mount over the 2 holes and install the flat head screws.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash Installed Showing Location



05-16-17

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2017 PanaVise Products, Inc.